

This manual applies to the following passenger cars, starting 1977:

Model	Model Year From To	Chassis Type	Engine Type	Auto. Transmission Type	Power Steering Type
230	1977 1978	123.023	115.954	722.119 (W 4 B 025)	765.700 (LS 90)
240 D	1977 1983	123.123	616.912	722.117 (W 4 B 025) 716.005 (G 76/18 C) ¹⁾	765.700 (LS 90)
300 D	1977 1982	123.130	617.912	722.118 (W 4 B 025)	
300 CD	1978 1982	123.150	617.912	722.118 (W 4 B 025)	
300 TD	1979 1981	123.190	617.912	722.118 (W 4 B 025)	
280 E	1977 1981	123.033	110.984	722.112 (W 4 B 025)	765.704 (LS 90)
280 CE	1978 1981	123.053	110.984	722.112 (W 4 B 025)	
300 TD-Turbo	1981 1985	123.193	617.952	722.303 (W 4 A 040)	
300 D-Turbo	1982 1985	123.133	617.952	722.315 (W 4 A 040)	
300 CD-Turbo	1982 1985	123.153	617.952	722.315 (W 4 A 040)	

¹⁾ Manual Transmission